


SPIRITTM

JACK STRAW

Installation and Operating Instructions

Keep all plastic and wire parts away from children.

WARNING: DO NOT TURN ON THE PROP UNTIL FULLY ASSEMBLED. STAY CLEAR OF THE PROP WHILE OPERATING.



PARTS:

A: Wood base

B: Pants

C: Pole with mechanism

D: Springs

E: Knee form with foam (2x)

F: Zip ties

G: Support Pole

H: Head with shoulder form

I: Screws

J: Coat with IR sensor

K: Right Arm

L: Left Arm






M: Control Box

N: Sand Bag

O: Adapter

Assembly:





1. Place the pants (Part B) on the base (Part A) with the pole support mount going through the rope. See Fig. 1.
2. Fully extend pole with mechanism (Part C). See Fig. 2.
3. Attach springs (Part D) to the pole with mechanism (Part C). See Fig. 3.
4. Attach the pole with mechanism (Part C) to the base (Part A), match A to A, by going through the opening in the back of the pants (Part B). Spring pin will lock in place. See Fig. 4.
5. Attach knee form with foam (Part E) to the pole with mechanism (Part C) by inserting the metal into the hole in the plastic piece located on the pole with mechanism (Part C). Secure on both sides with the zip ties provided (Part F). See Fig. 5a and 5b.
6. Attach loops on the pants (Part B) to the plastic hooks on the pole with mechanism (Part C). See Fig. 6.
7. Attach support pole (Part G) to pole with mechanism (Part C). Spring pin will lock in place. See Fig. 7.
8. Attach the head with shoulder form (Part H) to the support pole (Part G), matching C to C. See Fig. 8.
9. Secure the head with shoulder form (Part H) to the support pole (Part G) using the screws (Part I) provided. See Fig. 9.



10. Connect metal chain from the back of the head with shoulder form (Part H) to the chain from the pole with mechanism (Part C) using the provided hook and loop on the chains. See Fig. 10.
11. Put the coat with IR sensor (Part I) on the shoulder form (Part H) and secure by aligning the Velcro on the shoulder form (Part H) to the Velcro on plaid fabric of the coat with IR sensor (Part J). See Fig. 11.
12. Thread the right arm (Part K) through the sleeve of the coat with IR sensor (Part J) and insert the metal end of the arm into the plastic bar under the head with shoulder form (Part G). Make sure it is embedded into the slot in the plastic bar and secure the arm in place with the zip tie (Part F) provided. See Fig. 12.
13. Thread the left arm (Part L) through the sleeve of the coat with IR sensor (Part J) and insert the metal end of the arm into the plastic bar under the head with shoulder form (Part H). Make sure it is embedded into the slot in the plastic bar and secure the arm in place with the zip tie (Part F) provided. See Fig. 13.
14. Hang control box (Part M) from the hook on the side of the pole with mechanism (Part C). See Fig. 14.
15. Connect the wires from pole with mechanism (Part C) and head with shoulder form (Part H) to the matching wire from the control box (Part M) and connect the IR sensor wire to the IR sensor jack.
- 16.(Optional) Fill the provided sand bag (Part N) and place on base (Part A) to add weight for more stability.

IMPORTANT INFORMATION:

1. **The infrared sensor distance and ambient temperature are directly related. When the body temperature (98.6° F) is different to the ambient air temperature, the infrared sensor distance will be farther. When the body temperature (98.6° F) is close to the ambient air temperature, the infrared sensor distance will be shorter.**
2. **Do not use this item in an environment where air currents are caused by a window, air conditioning, or air outlet.**
3. **Do not have the infrared sensor face a direct source of heat such as a heater.**




OPTIONAL STEP PAD SETUP

Follow steps 1 through 16 on the installation instructions first, then:

1. Connect the wire from the optional Step Pad to the jack labeled “STEP PAD” on the control box. See Fig. 17.
2. Step on the Step Pad to activate the prop. See Fig. 18.

Step Pad (SKU #01181288) is sold separately and can be purchased in-store and online at www.SpiritHalloween.com



OPTIONAL EXTERNAL SPEAKER SETUP

This prop can be played through an external speaker (sold separately). To use this feature, follow steps 1 through 16 on the installation instructions first, then:

1. Connect the wire from your external speaker to the jack labeled “SPEAKER” on the control box. See Fig. 19.
2. Adjust the volume level to suit. See Fig. 20.


Note: Use external speakers with an impedance of 8 ohms only.



OPTIONAL MULTI-PROP REMOTE SETUP

Follow steps 1 through 16 on the installation instructions first, then:


1. Connect one of the transponders to the prop by inserting the wire of the transponder into either the Try Me or Step Pad jack as labeled on the control box. See Fig. 21.
2. Flip the switch on the transponder to the ON position.
3. Click the button on the Multi-Prop Remote that matches letter on the transponder to activate the prop. See Fig. 22.



OPTIONAL BATTERY ADAPTER SETUP

Follow steps 1 through 16 on the installation instructions first, then:

1. Install 4 D Batteries into Spirit Battery Adapter. See Fig. 24.
2. Connect wire from Spirit Battery Adapter to the 6V2A adapter port on the control box. See Fig. 24.
3. Turn switch on Battery Adapter to the ON position to power the prop.



BATTERY INSTALLATION

Battery installation should be performed by an adult.

- Use only batteries recommended in the instructions.
- Do not mix old and new batteries.
- Do not mix alkaline, rechargeable, standard, or different types of batteries.
- Be mindful to insert batteries with correct polarity as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from toy before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.

WARNINGS:

- This product is designed for indoor or covered porch use only, and should not be placed outdoors subject to the weather.
- This item is not a toy. For decoration only.
- Choking hazard due to small parts.
- Keep all plastic and wire parts away from children.
- This product is intended for use by persons 15 years of age and older. Not intended for use by children ages 14 and under.



DO NOT RETURN THIS ITEM TO THE STORE!
If experiencing technical difficulties, please email:
DrZombie@spirithalloween.com, or call
1-866-586-0155 or go to SpiritHalloween.com for assistance.



Distributed by
Spirit Halloween
6826 Black Horse Pike
Egg Harbor Township, NJ
08234-4197
MADE IN CHINA